




VIKING ARM

VIKING ARM® Tool Load Diagram

Lifting an object over maximum recommended weight with one VIKING ARM® Tool or improper placement of a load may result in bent lifting bars/base plate. Such use of the tool is not covered by our product warranty. Please study carefully Load Diagrams before you start working with your VIKING ARM® Tool.

Recommended maximum load equally distributed
on **both lifting bars**, kg



Recommended maximum load on **one lifting bar**, kg

